


TSS Gateway Installation

1

What's Inside

Check that following items are included in the package:



1. TSS Gateway



2. Power Cable




The installation guide is provided separately via email.

2

Firstly, mount the two antennas. Once ready, connect the TSS Gateway and place it as close as possible to where you handle the shipments or launch the loggers. The distance should not exceed 30 meters.

A green light will indicate that the TSS Gateway is powered and has cellular connectivity.

Please note that this can take up to 15 minutes.



The installation is completed once a fixed green light is shown on the TSS Gateway.